

Jake Brake® Update Kit

Model 317B to

Model 317C




FIG. 1

Update Kit, P/N 020642

P/N	Part Name	Quantity/ Kit
011251	Control valve collar	6
011252	Control valve cover	6
011283	Control valve	6
011284	Retaining ring	6
014619	Harness	3
015906	Seal	3
01-016440	Solenoid (contains seals)	3
018697	Control valve cover insert	6
019190	Control valve outer spring	6
019504	Control valve inner spring	6
019372	Master piston spring	1
	6-pack (019353)	
020644	ID plate	1
020649	Adhesive kit	1
021492	D-Lash™ assembly (6-pack)	1

Introduction

Recommended Torque Values

Jacobs Parts	Lb.-ft.	N•m
Cylinder head bolt	203	275
Cylinder head bolt spacers	65	88
Brake mounting stud assembly	70	95
Housing hold down nuts	59	80
Housing bolts, 190 mm	70	95
Housing bolts, 70 mm	41	55
Slave piston adjusting screw locknut	25	35
Spacer bolts (cover)	5	7
Solenoid valve	5	7

Caterpillar Parts

Valve bridge adjusting screw locknut	18	25
Ex. rocker arm adjusting screw locknut	18	25
Injector rocker arm adjusting screw	41	5


317C Application and Adjustment

Engine	Model Year	Serial Number	Horsepower	Slave Lash
3176	1992	7LG07500 and greater	325 - 350	0.020"



Update Instructions

These instructions describe how to properly remove, clean and reinstall engine brake components. Use an OSHA-approved cleaning solvent when washing parts. Be sure to coat parts with clean engine oil when reinstalling them.



NEVER REMOVE ANY ENGINE BRAKE COMPONENT WITH THE ENGINE RUNNING. PERSONAL INJURY MAY RESULT.

Solenoid Valve



DO NOT DISASSEMBLE OR TAMPER WITH THE SOLENOID VALVE. ENGINE DAMAGE COULD RESULT. THE SOLENOID VALVE IS NOT FIELD SERVICEABLE.

1. Disconnect the solenoid harness. Using a 7/8" socket and extension, unscrew the solenoid valve.
2. Remove and discard the three solenoid valves and three rubber seals per solenoid valve. If the lower ring stays in the bottom of the housing solenoid bore, remove it with a seal pick.
3. Clean out the solenoid valve bore in the housing. Use clean paper towels. Never use rags, as they may leave lint and residue which can plug the oil passageways.
4. Coat the new solenoid seal rings with clean lube oil. Install the upper (A, Fig. 2) and center (B) seal rings on the solenoid body and the lower (C) seal ring into the bottom of the solenoid bore in the housing.
5. Be sure the seals are seated properly. Carefully screw the solenoid into the housing without unseating the seals. Torque the solenoid valve to 110 lb.-in. (12 N•m). Be careful not to twist the seals while installing.




FIG. 2

Control Valve



THE CONTROL VALVE COVERS ARE UNDER LOAD FROM THE CONTROL VALVE SPRINGS. BE SURE TO REMOVE THE CONTROL VALVE COVERS CAREFULLY TO AVOID PERSONAL INJURY.

1. Apply pressure on the control valve cover and rotate the retaining ring ears to the slot in the housing (see Fig. 3). Remove the retaining ring using retaining ring pliers.




FIG. 3

2. Slowly remove the cover until spring pressure ceases, then remove the two control valve springs (see 4, Fig. 4), insert (6) and collar (3).
3. Using needle-nose pliers, reach into the bore and grasp the stem of the control valve (5). Remove the control valve.




FIG. 4

4. Discard all parts and replace them with new parts from the Update Kit.
5. Thoroughly clean the control valve bore in the housing using clean paper towels.
6. Reassemble the parts, reversing the removal procedure.



BE SURE THE CONTROL VALVE COLLAR IS INSTALLED WITH THE LONGER SLEEVE AREA UP (SEE FIG. 5). IF THE COLLAR IS INSTALLED UPSIDE DOWN, ENGINE DAMAGE MAY RESULT.




FIG. 5

7. Rotate the retaining ring so that the ears are located away from the slot in the housing as shown in Fig. 6.




FIG. 6

Master Piston

1. Press down on the master piston retaining washer to relieve the spring force. While holding the washer, use a pair of snap ring pliers to remove the retaining ring from the groove. Carefully release the retainer and remove it along with the old spring.
2. Remove the master piston from the bore. Clean in an approved solvent and inspect for wear on the piston and foot. Also inspect the bore.
3. Install a new master piston return spring by inserting the small end into the bore. The large coil, identified by **WHITE** paint, **should be facing out**.
4. Place the retaining washer and snap ring over the foot of the master piston and compress them into the bore. Using snap ring pliers, replace the snap ring in the groove to retain the master piston.




FIG. 7

5. Ensure the snap ring is properly engaged in the groove by gently grasping the master piston foot and pulling out until the master piston bottoms on the retaining washer. Release the master piston. If the assembly is correct, all parts should return to their original position.
6. Repeat this procedure on the remaining 5 locations.

NOTE:

AFTER THE NEW SPRING IS INSTALLED WITHIN THE RETAINING WASHER AND SNAP RING, IT IS NORMAL TO BE ABLE TO SEE THE SPRING IN THE BORE AROUND THE RETAINING WASHER.

Slave Piston Adjusting Screw

1. Loosen the slave piston adjusting screw locknut and remove the adjusting screw from the housing (see Fig. 8).




FIG. 8

NOTE:

THE PART NUMBER FOR THE SCREW IS LOCATED AT THE TOP OF THE SCREW NEXT TO THE SCREWDRIVER SLOT.



DO NOT ADJUST OR TAMPER WITH THE ADJUSTING SCREW ASSEMBLY. ENGINE DAMAGE COULD RESULT.

2. Remove the locknut from the screw. Remove and discard the slave piston adjusting screw. Replace it with the D-Lash™ assembly included in the Update Kit, using the old locknut.

Nameplate

1. Gently pry the old nameplate until it starts to loosen.
2. Grab the rivets with vice grips and pull up to remove.
3. Follow the instructions contained in the Adhesive Kit and apply the new nameplate to the housing.

Jacobs

.....
Jacobs® and Jake Brake® are registered trademarks and D-Lash™ is a trademark of Jacobs Vehicle Equipment Company
22 East Dudley Town Road • Bloomfield CT 06002

© 1995 Jacobs Vehicle Equipment Company
Printed in USA 11/95 P/N 020647